Boxoft Image To PDF Demo. Purchase from www.Boxoft.com to remove the watermark

これが THIS IS THE FAMILY COMPUTER!! ファミリーコンピュータ™だ!!

ディスクシステム編 DISK SYSTEM VOLUME

Nintendo®







TRANSLATED BY WWW.HIGSBY.NET





TRANSLATED BY WWW.HIGSBY.NET





TRANSLATED BY
WWW.HIGSBY.NET







TRANSLATED BY WWW.HIGSBY.NET

SO IF YOU TAKE YOUR DISK CARD TO THE STORE, YOU CAN USE THE DISK WRITER TO HAVE A DIFFERENT GAME WRITTEN TO IT.



TRANSLATED BY WWW.HIGSBY.NET







TRANSLATED BY WWW.HIGSBY.NET







TRANSLATED BY WWW.HIGSBY.NET



TRANSLATED BY
WWW.HIGSBY.NET





TRANSLATED BY WWW.HIGSBY.NET



② SET THE CONSOLE ON TOP OF THE DISK DRIVE.



① INSERT 6 C BATTERIES INTO THE DISK DRIVE.



④ CONNECT THE RAM ADAPTER'S PLUG TO THE RAM ADAPTER PORT ON THE BACK OF THE DISK SYSTEM.



③ INSERT THE RAM ADAPTER INTO THE 60 PIN CONNECTOR.





TRANSLATED BY WWW.HIGSBY.NET











TRANSLATED BY WWW.HIGSBY.NET











TRANSLATED BY WWW.HIGSBY.NET











TRANSLATED BY WWW.HIGSBY.NET



TRANSLATED BY WWW.HIGSBY.NET







TRANSLATED BY WWW.HIGSBY.NET







TRANSLATED BY WWW.HIGSBY.NET







TRANSLATED BY WWW.HIGSBY.NET



TRANSLATED BY WWW.HIGSBY.NET





TRANSLATED BY WWW.HIGSBY.NET



INSIDE OF A DISK CARD THERE IS A PLASTIC DISK COVERED WITH A THIN LAYER OF IRON OXIDE KNOWN AS THE MAGNETIC FILM. A MAGENTIC PATTERN (THE GAME) IS WRITTEN ONTO IT IN A SPIRAL FORMATION.



TRANSLATED BY WWW.HIGSBY.NET



TRANSLATED BY WWW.HIGSBY.NET

ONCE THE DISK CARD IS SET INSIDE THE DISK DRIVE, THE HEAD MAKES CONTACT WITH THE MAGNETIC FILM AND THE FILM BEGINS TO SPIN. THE HEAD THEN TRACES THE SPIRAL AND READS THE MAGNETIC PATTERN.









TRANSLATED BY WWW.HIGSBY.NET

THE DISK CARD IS THE SAME AS A RECORD. THE DISK DRIVE IS LIKE A RECORD PLAYER, AND THE RAM ADAPTER WORKS THE SAME AS A FAMICOM GAME CARTRIDGE.

SO IT'S LIKE THIS.





TRANSLATED BY WWW.HIGSBY.NET



THE RAM ADAPTER IS A LITTLE BIT DIFFERENT FROM ROM CARTRIDGES, AS WHILE IT CAN HOLD GAMES AND OTHER KINDS OF DATA...

WHEN THE CONSOLE IS TURNED OFF, THE MAGNETIC PATTERN LOADED INTO ITS MEMORY WILL BE COMPLETELY ERASED.







TRANSLATED BY WWW.HIGSBY.NET





TRANSLATED BY WWW.HIGSBY.NET











TRANSLATED BY WWW.HIGSBY.NET

SO IT'S LIKE THIS.

IRON POWDER

PAPER PAD

IF YOU PUT IRON POWER ON TOP OF A PAPER PAD IN THE SHAPE ON THE LETTER 'A'...

N

S

THEN YOU PUT A MAGNET TO THE BOTTOM OF THE PAPER PAD, THE IRON POWDER THAT'S CLOSE TO IT WILL BE PULLED IN AND DISTORT THE SHAPE.

BRINIGNG A MAGNET CLOSE TO IT COULD CAUSE THE PATTERN TO CHANGE.

BECAUSE THE MAGNETIC FILM HAS IRON OXIDE IN IT...

WOW, KYOUKO-CHAN. YOU'RE JUST AS SMART AS ME!

TRANSLATED BY WWW.HIGSBY.NET









TRANSLATED BY WWW.HIGSBY.NET









TRANSLATED BY WWW.HIGSBY.NET









TRANSLATED BY WWW.HIGSBY.NET

TRANSLATED BY WWW.HIGSBY.NET

TRANSLATED BY WWW.HIGSBY.NET

① DON'T TOUCH THE MAGNETIC FILM.

FOLLOW THESE GUIDELINES WHEN IT COMES TO DISK CARDS!

② DON'T STORE THEM IN HOT OR COLD PLACES.



③ DON'T PLACE THEM NEXT TO DEVICES THAT PRODUCE MAGNETISIM SUCH AS TVS OR RADIOS. ALSO KEEP THEM AWAY FROM MAGNETS AND ELECTRONIC KEYS.

④ DON'T DROP OR STEP ON THEM.

⑤ BEWARE OF CONDENSATION.



⑥ ALWAYS STORE THEM INSIDE OF THEIR DISK CARD CASE.

TRANSLATED BY WWW.HIGSBY.NET

IF YOUR FAMICOM DISK SYSTEM STOPS WORKING...

IF YOU ARE USING YOUR FAMICOM CORRECTLY AND IT HAPPENS TO STOP WORKING, PLEASE CONTACT EITHER THE STORE YOU BOUGHT IT FROM OR THE CLOSEST NINTENDO STORE TO YOU AS PRINTED IN THE INSTRUCTION MANUAL OR PAMPHLET.

YOUR FAMICOM WILL BE REPAIRED AND RETURNED TO YOU AS QUICKLY AS POSSIBLE, SO WHEN DROPPING IT OFF PLEASE IDENTIFY WHAT THE PROBLEM IS.

IF IT HAS BEEN 6 MONTHS OR LESS SINCE THE TIME OF PURCHASE, YOUR FAMICOM WILL BE REPAIRED FREE OF CHARGE. PLEASE BE SURE TO BRING YOUR RECEIPT WITH YOU.

PLEASE BE AWARE THAT IF THE NAME OF THE STORE THE FAMICOM WAS PURCHASED FROM, PURCHASE DATE, AND OTHER REQUIRED INFORMATION ARE NOT PRINTED ON THE RECEIPT, YOU WILL BE CHARGED FOR THE REPAIR.

TRANSLATED BY WWW.HIGSBY.NET

発行：任天堂株式会社　京都市東山区福稲上高松町60番地 TEL. 075-541-6113
漫画：野崎 泰
編集：株式会社漫画社
©1985 Nintendo・野崎 泰

無断複製・転用を禁ず　非売品 860108-100